

Operating Instructions for Cobra and Lynx Duct Leakage Testers



Table of Contents

Introduction

Introduction	2
--------------------	---

Safety Precautions

Safety Precautions	2
--------------------------	---

Prior to Testing

Are You Using the Correct Tester?	3
System Preparation	3
Power Requirements	3
Extension Cord Requirements	4
Flex-Duct Length	4
Determining Maximum Allowable Leakage	4
Determining Which Orifice Plate to Use	5 - 6

Duct Leakage Test Setup and Procedure

Install Orifice Plate and Upper Tube Section	7 - 8
Connect Flexible Duct to Orifice Tube	9
Connect Flexible Duct to Duct System	9
System Test Pressure Connection	10
Duct Leakage Test Setup (SUPPLY)	11
Duct Leakage Test Setup (RETURN/EXHAUST)	12
Zeroing Pressure Gauges	13
Avoiding Over-Pressurization	14
Obtaining System Test Pressure	14 - 15
Determining Leakage Rate.....	15 - 17

Troubleshooting

Can't obtain system test pressure	17
Zero reading on "DUCT SYSTEM" gauge	18
Zero reading on "ORIFICE TUBE" gauge	19
"ORIFICE TUBE" gauge reading maxed out.....	19

Introduction

These operating instructions are for ORIFLOW models COBRA and LYNX air leakage testers. Take pride in knowing that you have purchased the best air leakage tester on the market. It is no secret that Oriflow manufactures the highest quality testers, and has unparalleled customer service and technical support.

The orifice plates available for your duct leakage tester are constructed from laser-cut 0.063-inch stainless steel and do not require recalibration for 5 years. Note the authority having jurisdiction may override this requirement, and if so, Oriflow has reasonable rates for re-calibrating orifice plates manufactured by Oriflow.

Safety Precautions

Before operating your tester, read the following safety precautions:

- ✓ DO NOT operate the tester in the rain,
 - ✓ DO NOT operate the tester while it is near or in water,
 - ✓ DO NOT operate the tester with a damaged electrical cord or plug,
 - ✓ DO NOT remove the inlet safety screen,
 - ✓ DO NOT touch the blower wheel when the unit is plugged in,
 - ✓ DO NOT look into the discharge end of the tester when the unit is plugged in,
 - ✓ DO NOT use the tester as a ladder or step stool,
 - ✓ DO NOT allow children near the tester,
-
- ✓ DO use an extension cord of the proper gauge (see *Table 2*),
 - ✓ DO use the proper voltage and line frequency listed on the motor nameplate,
 - ✓ DO lock the caster when the tester is positioned horizontally,
 - ✓ DO use the tester on level ground,
 - ✓ DO secure the tester when transporting it,
 - ✓ DO wear proper hearing protection, safety glasses and work gloves,
 - ✓ DO seek assistance when lifting the tester (e.g., loading onto truck, going up or down stairs).

Prior to Testing

Are you Using the Correct Tester?

See Table 1 for the maximum capacity for each duct tester when using the largest orifice plate.

Table 1 – Duct Leakage Tester Capacities

Model	Maximum Leakage Capacity (cfm)*											
	System Test Pressure (in.wg.)											
	0.10	1	2	4	6	7	8	9	10	12	14	16
Lynx	570 cfm	550 cfm	540 cfm	455 cfm	290 cfm	160 cfm	—	—	—	—	—	—
Cobra	680 cfm	650 cfm	645 cfm	600 cfm	465 cfm	405 cfm	350 cfm	250 cfm	—	—	—	—
Panther	1400 cfm	1350 cfm	1320 cfm	1210 cfm	1065 cfm	1065 cfm	875 cfm	875 cfm	615 cfm	270 cfm	—	—
Rhino	1700 cfm	1630 cfm	1550 cfm	1420 cfm	1330 cfm	1330 cfm	1185 cfm	1185 cfm	1035 cfm	895 cfm	660 cfm	480 cfm

* – Using the largest sized orifice available for the model listed.

System Preparation

Cap off all ends of system using clear plastic and duct tape or sheetmetal duct end caps. Make sure you test the part of the duct system that leakage testing is required. Usually, this is from the system fan up to, but not including, the VAV boxes (terminal units). Refer to the engineer's specifications and all applicable codes and test standards.

Power Requirements

Do you have an adequate power supply for your tester (see *Table 2*)?

Table 2 – Tester Amp Draw

Tester Model	Voltage	Flow Control Option	Full Load Amps
Lynx	115	Slide Gate	12.7
Cobra	115	Slide Gate	12.8
Cobra	115	VFD	14.0
Cobra	230	Slide Gate	6.4
Cobra	230	VFD	8.0

Extension Cord Requirements

If you need an extension cord, is it the proper gauge? See *Table 3* below for extension cord requirements.

Table 3 – Required Extension Cord Wire Gauge

Tester Model	Flow Control Option	Voltage	Extension Cord Length (feet)	Wire Gauge
Lynx or Cobra	Slide Gate	115	10 to 50	14
			50 to 100	12
Cobra	Slide Gate	230	10 to 50	14
			50 to 100	14
Cobra	VFD	115	10 to 50	14
			50 to 100	12
Cobra	VFD	230	10 to 50	14
			50 to 100	14

Flex-Duct Length

Make sure you have enough flexible-duct with your tester for the job. Each tester includes 12.5 feet, which is enough for most applications. Extra lengths of flexible-duct are available at www.oriflow.com/products.

Determining Maximum Allowable Leakage

To determine the maximum allowable leakage for the project, use ORIFLOW’s **free online programs** to make these calculations (www.oriflow.com/programs).

In the U.S., calculations are done for either of the two typical specifications:

1. Percentage of system flow, or
2. SMACNA Leakage Class.

In Europe, Australia and other countries outside of the U.S., the following specification is commonly used:

1. Pressure Classification (Class A, B, C or D)

If the specification uses SMACNA Leakage Class or Pressure Class, you will need to calculate the total duct system surface area.



Oriflow has FREE Adobe forms available that will calculate duct surface area given the duct shape, dimensions and length (www.oriflow.com/freeform). These forms also calculate Leakage Factor, allowable leakage and Pass/Fail criteria among other calculations.

Determining Which Orifice Plate to Use

After determining the allowable leakage at the system test pressure, refer to the following tables for the capacities of each orifice plate available for the Cobra and Lynx model testers. The proper plate is the one where the specified allowable leakage falls between the minimum and maximum leakage at the system static pressure.

For example, if you are testing a system at 4 in.wg. pressure and the maximum allowable leakage is 350 cfm, you will need a 3-inch orifice plate if using the Cobra tester (see Table 6) or a 4-inch plate if using the Lynx tester (Table 7).

Table 4 – Tester Capacities using the 1-inch Orifice Plate*

System Static Pressure (in.wg.)	Minimum Leakage** (cfm)	COBRA Tester Maximum Leakage (cfm)	LYNX Tester Maximum Leakage (cfm)
0.10	9	47	37
1	9	44	34
2	9	42	32
3	9	39	27
4	9	36	23
5	9	32	17
6	9	29	15
7	9	24	6
8	9	19	--
9	9	12	--

* If you need to measure lower flow rates, contact us about the 'low-flow' orifice plate.

** Recommended minimum based on 0.40 in.wg. across orifice plate.

Table 5 – Tester Capacities using the 2-inch Orifice Plate

System Static Pressure (in.wg.)	Minimum Leakage** (cfm)	COBRA Tester Maximum Leakage (cfm)	LYNX Tester Maximum Leakage (cfm)
0.10	34	180	160
1	34	170	150
2	34	165	135
3	34	155	120
4	34	140	105
5	34	125	85
6	34	115	65
7	34	95	25
8	34	75	--
9	34	45	--

** Recommended minimum based on 0.40 in.wg. across orifice plate.

Determining Which Orifice Plate to Use (continued)

Table 6 – Tester Capacities using the 3-inch Orifice Plate

System Static Pressure (in.wg.)	Minimum Leakage** (cfm)	COBRA Tester Maximum Leakage (cfm)	LYNX Tester Maximum Leakage (cfm)
0.10	82	440	375
1	82	420	355
2	82	410	340
3	82	390	320
4	82	375	285
5	82	340	230
6	82	290	170
7	82	245	55
8	82	195	--
9	82	130	--

** Recommended minimum based on 0.40 in.wg. across orifice plate.

Table 7 – Tester Capacities using the 4-inch Orifice Plate

System Static Pressure (in.wg.)	Minimum Leakage** (cfm)	COBRA Tester Maximum Leakage (cfm)	LYNX Tester Maximum Leakage (cfm)
0.10	175	680	570
1	175	650	550
2	175	645	540
3	175	630	510
4	175	600	455
5	175	545	365
6	175	465	290
7	175	405	160
8	175	350	--
9	175	250	--

** Recommended minimum based on 0.40 in.wg. across orifice plate.

Install Orifice Plate and Upper Tube Section

The orifice plate that was determined from the previous section should now be installed with the serial number facing upwards so the corresponding calibration certificate may be referenced after installation. Refer to *Figures 1* through *4*.



Figure 1 – Install Orifice Plate and then Rotate Clockwise




Figure 2 – Rotate Orifice Plate Clockwise until it Locks in Place

Install Orifice Plate and Upper Tube Section (continued)

After the orifice plate is locked in place, place the upper tube section over the bolt/wing nut set, rotate clockwise, and tighten wing nuts (Figures 3 and 4).



Figure 3 – Install Upper Tube Section and Rotate Clockwise



Figure 4 – Tighten Wing Nuts after Rotation

Connect Flexible Duct to Orifice Tube

See Figure 5 below for securing one end of the flexible duct to the orifice tube. Note that the worm-gear clamp should be slid over the flex-duct **before** connecting it to the orifice tube. Slide the flexible duct so that it overlaps the orifice tube 2 to 3 inches, and tighten clamp using a 5/16-inch nut driver.




Figure 5 – Installing Flex-Duct on Tube

Connect Flex-Duct to Duct System

Connect the 6-inch end of the flex-duct to the duct system. Find a convenient location in the duct system where the tester has easy access. Make sure the connection is a sturdy, sealed tight connection. You don't want to create a leaky connection thereby adding to the system leakage.



Figure 6 – Connection to Duct System

System Test Pressure Connection

Refer to Figures 7 and 8. To monitor the system static pressure, you need to drill a 5/16-inch diameter hole at least 3 feet away from the flex-duct connection. Next, insert the grey, plastic static pressure tap that is located on the end of the pressure tubing coming from the “DUCT SYSTEM” gauge. Seal the pressure tap to the duct wall using duct tape (Figure 7).

If the static pressure tap is missing, just insert end of pressure tubing from the “DUCT SYSTEM” gauge so that 6 to 12 inches of tubing is inside the duct system. Using putty or duct tape, seal the connection. See *Figure 8*.




Figure 7 – Connection to Duct System using Static Pressure Tap




Figure 8 - Static Pressure Tubing Connection

Duct Leakage Test Setup (SUPPLY)

See *Figure 9* for the test setup for SUPPLY duct system testing (positive pressure testing). On the backside of the DUCT SYSTEM pressure gauge, move the pressure tubing to the pressure port labeled SUPPLY SYSTEM.




Figure 9 – Duct Leakage Test Setup for a SUPPLY System

Duct Leakage Test Setup (RETURN/EXHAUST)

Refer to *Figure 10* for the test setup required to measure air leakage of a RETURN/EXHAUST system (negative pressure testing). On the backside of the DUCT SYSTEM pressure gauge, move the pressure tubing to the pressure port labeled RETURN SYSTEM.

Connect the 6-inch end of the flex-duct to the inlet of the blower so that air from the system is drawn into the blower. You will determine the leakage of the system since the air drawn from the blower is discharged through the orifice plate which you are measuring.




Figure 10 – Duct Leakage Test Setup for a RETURN/EXHAUST System

Zeroing Pressure Gauges

Before you turn on the tester, make sure both gauges have been zeroed.

Zeroing Analog Gauges

Using a small slotted screwdriver, turn the zero-adjustment screw on the gauge until the needle is aligned with the zero reading. Turning the screw clockwise increases the pressure reading; turning it counterclockwise decreases the reading. See *Figure 11*.



Figure 11 – Zeroing Analog Gauges

Zeroing Digital Gauges


First, turn on both gauges by pressing the black (or red) button located on the backside of each gauge.

Use the following steps to zero each digital gauge:

1. Press **MENU** button once.
2. Press **▼** arrow button until Adu shows on screen.
3. Press **E** button once to go into auto-zero mode
4. Press **E** button again and AUTO will be blinking on screen
5. Press **E** button a third time to complete the zeroing process.
6. Press **MENU** button two times to get back to the pressure reading.
7. Pressure should be reading zero or within +/- 0.02 in.wg. If not, repeat steps.



Avoid Over-Pressurization

Prior to starting the blower, shut the inlet slide gate on models without the speed controller option. For models with the VFD speed controller, press and hold the DOWN button  until the readout shows 10.00 (the lowest speed setting). If powering up for the first time, the reading will already be at 10.00. See Figure 12.




Figure 12 – Avoid Over-Pressurizing by Minimizing Air Delivery upon Startup (inlet slide model on left, VFD speed control model on right)

Obtaining System Test Pressure



Turn the blower on and slowly open the inlet slide gate (Figure 14) if your tester has an inlet slide gate. If your tester has the VFD speed controller, press the green RUN button, and then press the UP arrow button  to increase fan speed. Pressing and holding the UP button  will increase speed more quickly. See Figure 13.



Figure 13 – Obtaining System Test Pressure (inlet slide model on left, VFD speed control model on right)

Obtaining System Test Pressure (continued)


Regardless of tester model used, pay attention to the “DUCT SYSTEM” gauge while increasing airflow. When you have reached the required system static pressure, tighten the set-screw on the inlet damper (or STOP pressing the UP arrow button ).



Figure 14 – Duct System Gauge Reading (analog on left, digital on right)

Determining the Leakage Rate

Now that you have obtained the system test pressure, note the pressure reading of the ORIFICE TUBE gauge (Figure 15). Refer to your calibration certificate to determine the leakage rate that corresponds to the gauge reading. An example of a calibration certificate is shown in Figure 16; it is for informational purposes only and used in the example shown on the next page. **Always refer to the calibration certificate(s) that came with your calibrated orifice plate(s).**



Figure 15 –ORIFICE PLATE Gauge Reading (analog on left, digital on right)

**SAMPLE CALIBRATION CERTIFICATE
USE YOUR CERTIFICATE**

Issue Date:	03/17/16	Orifice Size:	3.0 inch	Material:	304 SS
Reference Meter:	50MC2-4	Orifice Serial #:	021553	Tube Diameter:	5 inches
Standard Temperature and Pressure (70 °F and 29.92 in.Hg.)					
"ORIFICE PLATE" Gauge Reading (in.wg.)	Leakage Rate (cfm)	"ORIFICE PLATE" Gauge Reading (in.wg.)	Leakage Rate (cfm)	"ORIFICE PLATE" Gauge Reading (in.wg.)	Leakage Rate (cfm)
0.0	0.0	1.7	175.3	3.4	247.9
0.1	42.5	1.8	180.3	3.5	251.5
0.2	60.1	1.9	185.3	3.6	255.0
0.3	73.6	2.0	190.1	3.7	258.6
0.4	85.0	2.1	194.8	3.8	262.0
0.5	95.0	2.2	199.4	3.9	265.5
0.6	104.1	2.3	203.9	4.0	268.8
0.7	112.5	2.4	208.2	4.1	272.2
0.8	120.2	2.5	212.5	4.2	275.5
0.9	127.5	2.6	216.7	4.3	278.7
1.0	134.4	2.7	220.9	4.4	282.0
1.1	141.0	2.8	224.9	4.5	285.1
1.2	147.2	2.9	228.9	4.6	288.3
1.3	153.3	3.0	232.8	4.7	291.4
1.4	159.0	3.1	236.7	4.8	294.5
1.5	164.6	3.2	240.5	4.9	297.6
1.6	170.0	3.3	244.2	5.0	300.6

You may use a calculator to calculate leakage using the "ORIFICE TUBE" gauge reading and the following equation:

$$\text{Leakage (cfm)} = 134.42 \times \sqrt{\text{ORIFICE TUBE Gauge Reading}}$$

Figure 16 – Example Calibration Certificate. Use the calibration certificate that came with your orifice plate

Example (refer to Figures 15 and 16)

For an ORIFICE TUBE gauge reading of 2.46 in.wg. (Figure 15), the leakage rate is approximately 210 cfm using the calibration certificate shown in Figure 16.

For an exact value, use the equation that comes with every calibration certificate. For the example shown in Figure 16:

$$\text{Leakage} = 134.42 \times \sqrt{\text{ORIFICE TUBE Gauge Reading}}$$

where the value of "134.42" is a constant and will be specific to the orifice plate used (**every plate has its own value; yours will be different**).

Using a calculator, take the square root of the gauge reading first, and then multiply by the constant for your orifice plate (for this example, the constant is "133.357"). The exact leakage is 134.42 x (square root of 2.46) = 210.8 cfm.



Oriflow has FREE Adobe forms available that will calculate the leakage, leakage factor, allowable leakage, Pass/Fail criteria and duct surface area among other variables (www.oriflow.com/freeform).

Troubleshooting

Can't obtain system test pressure (THIS IS THE MOST COMMON ISSUE)

This happens when the system is leaking too much air. Make sure all outlets are sealed. Check corners of rectangular duct for excessive leakage. Inspect all duct and fitting joints for leakage. Make sure you seal all suspect joints and allow to cure 24 to 48 hours. Always refer to duct sealant manufacturer's instructions.

Check for these other sources of leakage:

- Rectangular duct joints (check and seal corners),
- Fire or smoke dampers,
- Duct joints (pay particular attention to flex-duct joints if they are part of the leak test),
- VAV boxes (pay particular attention to parallel box back draft dampers),
- Built-up air handlers,
- Plenums,
- Uncured duct sealant blow-thru (follow manufacturer instructions for cure time),
- Improperly sealed joints,
- Hot water coils and electric heaters,
- Open duct end that was supposed to be sealed/capped-off for the leak test.

A non-toxic smoke machine is an excellent tool for locating significant sources of leakage. Call ORIFLOW at 727-400-4881 or online at www.oriflow.com for more information.

Zero reading on “DUCT SYSTEM” gauge

If the gauge reading is zero, refer to the table below to fix this problem. Perform troubleshooting steps in the order shown in the *Table 7* below.

Table 7 –Troubleshooting steps when “DUCT SYSTEM” gauge is zero

Step	Scenario	What to do
1	Inlet damper was left shut, cutting off air to the system.	Open inlet damper slowly.
2	Pressure tubing connected to gauge incorrectly	Look at the P1 and P2 stickers that are located on the orifice tube and gauges. Make sure tubing from P1 tap matches the P1 tap on the “ORIFICE TUBE” gauge.
3	Plugged fitting or malfunctioning gauge.	Gently blow through other end of pressure tubing from “DUCT SYSTEM” gauge, and watch needle increase pressure reading.
4	System is leaking too much air.	<p>Check for these other sources of leakage:</p> <ul style="list-style-type: none"> • Rectangular duct joints (check and seal corners), • Fire or smoke dampers, • Duct joints (pay particular attention to flex-duct joints if they are part of the leak test), • VAV boxes (pay particular attention to parallel box back draft dampers), • Built-up air handlers, • Plenums, • Uncured duct sealant blow-thru (follow manufacturer instructions for cure time), • Improperly sealed or un-sealed joints, • Hot water coils and electric heaters, • Open duct end that was supposed to be sealed/capped-off for the leak test.

Zero reading on “ORIFICE TUBE” gauge

If the gauge reading is zero, refer to the table below to fix this problem. Perform troubleshooting steps in the order shown in *Table 8* below.

Table 8 –Troubleshooting steps when “ORIFICE TUBE” gauge is zero

Step	Scenario	What to do
1	Inlet damper was left shut, cutting off air to the system.	Open inlet damper slowly.
2	Plugged pressure taps.	Remove pressure tubing from “ORIFICE TUBE” gauge, and blow through each end to make sure the pressure taps on the orifice tube are clear.
3	Orifice plate too large for application.	If you are using a 4-inch ID orifice plate, and the system is leaking 40 cfm, you probably won’t even notice the gauge needle moving. This can happen to other orifice plates too. You need to purchase an orifice plate with a smaller bore diameter so that a small amount of airflow/leakage will result in a bigger pressure drop.
4	System is leaking very little air.	You’ll know if this is true if the fan inlet is almost shut. Not likely unless system is small. Fix is to use plate with smaller bore.
4	Pressure tubing connected incorrectly.	Look at the P1 and P2 stickers that are located on the orifice tube and gauges. Make sure they match.
5	Malfunctioning gauge.	Remove the clear pressure tubing from the lower pressure tap on the orifice tube and blow through the end of the tubing. The needle should move in response. If not, the gauge is faulty.
6	Not sure	The best way to make sure that your tester is working properly is to disconnect the flex duct from the system and turn the blower on, and slowly open the inlet damper. If you feel a lot of air coming out of the tube end, you should see a pressure reading on the gauge “ORIFICE TUBE”.

“ORIFICE TUBE” gauge reading maxed out

- *Scenario 1:* The system is leaking too much air. Make sure all outlets are sealed. Check corners of rectangular duct for excessive leakage. Inspect all duct and fitting joints for leakage. Make sure you seal all suspect joints and allow curing time of 24 to 48 hours. Always refer to duct sealant manufacturer’s instructions.
- *Scenario 2:* orifice plate bore could be too small, causing a high pressure drop at low to moderate flows. You need an orifice plate with a larger bore.

ORIFLOW LLC
www.oriflow.com
 2125 Range Rd., Unit B
 Clearwater, Florida 33765
 727-400-4881 (phone)
 877-420-7091 (fax)
sales@oriflow.com